
C or Mac Computer Screen	Figure 1
	h 11 12
	in ×
·	
	*
	i
	EZ
fter the initial loading of the software, the user enters the front door of GSEN software by first clicking the logical part the right lower corner of the desktop. That click takes the user to the following part to the f	ng

.



Pictures, buttons, and images may appear in different places on our software pages, depending on how we do our layout for each celebrity, however, our functions and methods of access and manerverability will remain constant

GSEN software supports two separate kits. Kit A is the prerequisite purchase for the overall operation of the entire program.


This kit contains the smart card, the smart card terminal, the software CD, and instructions. The smart card terminal hooks to either the Serial or the USB port. The terminal is the tool that allows the smart card to communicate with the software. After Kit A has been purchased and loaded, the cardholder may expand his collection of celebrity endorsed smart cards through the purchase of Kit B. This kit contains only the smart card, the software cd, and appropriate instructions. Purchase of an additional smart card terminal is not necessary, as the one contained in Kit A is the only one needed for an individual computer on which the GSEN smart card will be used. As the user adds additional celebrity cards to his collection, the CD software will add the new celebrity's images and name to boxes 1,2,3, and 4. Boxes 1 and 4 are image boxes. Box 2 is a pull-down box that lists the name of each celebrity card on the computer (both from Kit A and Kit B). From that box, the user may select one of the other desired celebrities. When that happens, all corresponding boxes change to match the newly selected celebrity. When the "Go" button at #3 is activated, it sends the user to the main front page of the software.


Celebrity	pictures and logos here	Figure 3
Pin access only	Pin access only	
Credit Card and Address 1	Secure you Personal Sites 4	
Edit Credit Cards and 2 Addresses	Smart Fans Travel and More 5	
Pin access only	Nature Conservation	- -
Celebrities Smart Kids Homework Links	6 and 7 Victory Junction Gang	J

ship-to and ship-from addresses for easy record keeping and on-line shopping procedures. This form also allows memory space for storage of personal favorite sites, as well as travel information, favorite causes, and an all-important homework links for kids. Button 1 takes the user to the pin-number-required credit card and address page, where the user may enter numerous credit cards and corresponding billing addresses for those cards, as well as ship-to and ship-from addresses for on-line shopping ease. While shopping on line, the user can conveniently drag and drop credit card and shipping information into the on-line merchants order and shipping information forms. This is possible because GSEN application can run simultaneously beside the merchant's. Button 2 takes the user to the edit application for the credit card and address information, where the user can add, delete, or otherwise change the information contained here Button 3 is the SmartKids homework links page. When a user inserts the smart card, he is immediately taken to the celebrity's site. At the same time this is taking place, the GSEN site is notified to begin filling in the homework links for the user to access. From that point, the user saves the links to the smart card, which locks out anyone else from accessing that user's software Button 4 takes the user to the form where he can save his favorite URL's to his personal page settings. For security purposes, this Page is pin-number access only. Button 5 delivers the user to some of the best travel, shopping and services available on the Web. Buttons 6 & 7 provide direct access to some of the most popular non-profits and charities, such as Victory Junction Gang, a Petty Enterprises developed special camp for children with incurable and rare diseases.



	Kyles	Figure 3.1
EZ	DRAG-N-DROP	
VISA	Card Type	٠ ١
Text2 Text4	Card Number First Name	
Text6	Last Name	
Text8	EXPIRATION DATE	
Add Text13	dress1	
Add Text15	dress2	
Text17	ITY	
Text19	TATE	(1)
Text20	ZIP	
Text22	COUNTRY	
E	OONE	





	Secured Personal Fa	avorites. FIGURE 3.4
Insert SmartCard Now to	Enter up to 20 Personal Favorite S	les
		GO
A SECURITY OF THE SECURITY SEC		GO
		GO GO
		GO
	Control of the Contro	GO
		GO
MEDITAL	SAVE	DONE

Kyle's	Figure 3.5
Insert SmartCard now to receive GSN Partn	er Airline Links for discounts!
	GO
	GO
	GO
	GO
Or, Visit these sites for GSN Partner Hotel Links for	
	GO
	.GO
	GO
Also these for GSNPartner Car Rental Links for disc	ounts!
	GO
	GO
Or, visit these Online Shopping Discounts!	The second secon
	GO
	60
	GO
EDIT	SAVE DONE